

CRES activities on Sustainable Hydrogen Production

Dr. E. Varkaraki

RES & Hydrogen Technologies Integration Section

CRES, Pikermi, Attika, Greece

“Pathways to Sustainable Hydrogen Production in Europe”, EHA session, Brussels, February 1st, 2007



CRES activities on hydrogen technologies

CRES is active in the real-scale development and demonstration of RES – hydrogen systems

- Hydrogen production
- Hydrogen storage
- Hydrogen use as fuel

- Integrated system design and analysis
- Component testing and evaluation
- Evaluation of demonstrations and systems
- Techno-economical studies
- Modeling and simulation

Wind hydrogen test site (RES2H2)

Key Components	Key data
Start-up	October 2005
Wind Turbine	500 kW
Alkaline Electrolyser	25 kW, 5 Nm ³ /h H ₂ 20 bar 99.98 % v. purity
Metal hydride tanks	LaNi ₅ type 40 Nm ³ in MH tanks
Hydrogen compressor	Single stage 10 - 220 bar
Filling station	100 Nm ³ in cylinders



*General View of
wind-hydrogen installation*



Wind hydrogen test site (RES2H2)



“Pathways to Sustainable Hydrogen Production in Europe”, EHA session, Brussels, February 1st, 2007


Wind hydrogen test site (RES2H2)

Electrolyser operation under stable and variable power input



Wind hydrogen test site (RES2H2)

Electrolyser stack efficiency as a function of applied current density





Operating temperature under variable power lies in the range 45-70°C

Stack efficiency: 70-88% (HHV)

AC power efficiency: 60-75% (HHV)

Wind hydrogen test site (RES2H2)

Operation of Metal Hydride tanks



Wind hydrogen test site (RES2H2)

- Optimisation of component size and interfacing,
with respect to hydrogen flow, electricity and information flow
- Efficiency/cost analysis of the alkaline Electrolyser
- Efficiency/cost analysis of the Metal Hydride tanks
- Important margins for efficiency increase exist in:
 - power electronics of the electrolyser
 - wind turbine – electrolyser interface
 - optimisation of auxiliaries
 - heat management of the metal hydride tanks' operation

PV-Hydrogen laboratory



PEM electrolyser
Hogen RE

3 kW
0.5 Nm³/h H₂
13 bar
99.999 % v. purity



Alkaline electrolyser
ErreDue

3 kW
0.5 Nm³/h H₂
6 bar
99.5 % v. purity



Bioethanol Reformer
HEL BIO

0.6 Nm³/h H₂
1.3 bar
68 % v. purity

PV-Hydrogen laboratory

Conventional hydrogen storage tank

3 m³ volume

16 bar

40 Nm³ H₂ capacity




Metal Hydride Tanks

AB₅ type alloy

25 units of 1.1 Nm³ H₂ each

28 Nm³ H₂ capacity

PV-Hydrogen laboratory



PEM Fuel Cell
Plug Power (GenCore)

5 kW DC
99.95 %v. H₂ purity
4.5 Nm³/h H₂
8-12s for start-up
DC/AC inverter

Alkaline Fuel Cell
Astris Energy

1.8 kW DC
99.99 %v. H₂ purity
1.2 Nm³/h H₂
3 min. for start-up

Other components

Fuel cell test bench
Data control and acquisition system
Water deioniser
Water boiler
Water chiller